

INSTRUCTION

QT INSTALLATION GUIDE



QTSCU



STEP 1

After installing a perimeter isolation strip, apply approved adhesive to the subfloor using recommended trowel size.



STEP 2

Lay the QTscu into the adhesive bed.



STEP 3

Roll the QT with an approved flooring roller.



STEP 4

Apply thin set to the QT using TCNA recommended trowel size.



STEP 5

Lay floor finish.

QTRBM



STEP 1

After installing a perimeter isolation strip, QTrbm is easily rolled onto a smooth surface. It lays flat and will not slip or move.



STEP 2

Duct tape the seams.



NOTE:

QTrbm is durable enough for foot traffic, pouring equipment, and materials.



STEP 3

Pour a minimum 1" gypsum concrete surface that meets required sound ratings and passes structural requirements.



STEP 4

Prepare gypsum concrete surface for floor finish.